

CASH *DRAWERS*

A cash drawer is almost a compulsory accessory of every cash register. Cash drawers work with each Euro and POS-3000/4000 cash register. "Flip-top" cash boxes CDM-460 are suitable for Euro-2500 and POS-3000/4000 cash registers in self-service retail stores and supermarkets.



	CD-530	CD-840	CD-880	CDM-460	C-330	C-550	CD-SM 48 CD-BM 58	CD-MP 38 CD-BP 58	CDV-68 Flip-Top
Opening	Electrical	Electrical	Electrical	Electrical	Mechanical	Mechanical	Electrical	Electrical	Electrical
Number of notes	4	4	8	4	3	3	4/5	3/5	6
Number of coins	5	8	8	8	5	5	8/8	8/8	8
Removable coin insert	✓	✓	✓	✓	—	—	✓	✓	✓
Lock	✓	✓	✓	✓	✓	✓	✓	— / ✓	✓
Dimensions	103 × 350 × 405	110 × 410 × 415	110 × 410 × 415	100 × 170 × 460	160 × 330 × 405	160 × 330 × 405	105 × 370 × 425 105 × 430 × 485	95 × 290 × 350 105 × 435 × 440	100 × 460 × 170
Opening direction	Drawer	Drawer	Drawer	Flip - top	Drawer	Drawer	Drawer	Drawer	Flip - top
Material / Colour	Metal / Light	Metal / Light	Metal / Light	Metal / Light	Metal / Light	Metal / Light	Metal / Black	Plastic / Black	Metal / Black